


CLEARLINE[®]

Intelligent Foot Warmer Model FW - 01






INSTRUCTION MANUAL

Please read and retain these instructions for future reference

Thanks for buying the Intelligent Foot Warmer. Before using the product, please read these instruction manual carefully and operate the product based on the instructions.

E. Safety Instruction


1. This appliance is not a toy. Do not let children play with it.
2. Close supervision is necessary when the appliance is used by or near children.
3. When not in use, please switch off the main socket, & remove the power cord.
4. Please don't use the foot warmer near bathtub, shower sprayer & the pool.
5. WARNING: In order to avoid over-heating, It is not advisable to cover it.
6. Do not use the appliance if cord or appliance shows any signs of damage. Should the cord be damaged, it must be replaced by a qualified electrician.
7. To protect against fire, electric shock or personal injury, do not immerse cord, electric plug, or main unit in water or other liquids.
8. Never try to repair the foot warmer by yourself. All repairs should be made by a competent qualified electrician or by our service centre.



B. Technical Parameters

Product	Model Name	Rated Voltage	Rated Frequency	Rated Power
Foot Warmer	FW 01	230V~	50Hz	50W

C : Know your Intelligent Foot Warmer



D. To use

Put the plug in the socket, put the power switch to on position. Temperature can be adjusted as per preference of the user. If feet feel too hot put the fleece cover provided with the footwarmer on the feet on then place the wrapped feet on the footwarmer.

A. Product Feature

1. Lower energy consumption, yet warms up quickly.
2. Overheat protection.
3. Stepless temperature control mode, users can adjust the temperature according to their preference.
4. Ideal for aged people & for people with perennially cold feet.
5. Suitable for all foot sizes.

G. Maintenance

1. When ever dirty please wipe it with damp cloth.
2. Never use the petrol or any acids, it will damage the outer frame's surface.
3. When not in use switch off the mains & remove the plug from the socket.

CLEARLINE CUSTOMER SERVICE

This product carries a Warranty of 12 months from the date of purchase against defects caused by faulty workmanship and materials.

The Warranty excludes defects caused by the product not being used in accordance with instructions, misuse, accidental damage and tampering with by unauthorized persons,

In the event of any defect arising during Warranty period, the same should be taken to your nearest dealer or wholesaler. It will then be taken care off as per discretion of the company's representative.

Warranty Card

SERIAL No. _____

PURCHASER'S NAME & ADDRESS _____

DEALER'S NAME & ADDRESS _____

DEALER'S SIGNATURE _____

BILL NO. _____ DATE OF PURCHASE _____

Marketed By

CLEARLINE APPLIANCES LIMITED

177-G, Industrial Area, Phase-I, Chandigarh - 160 002 (INDIA)

In case of any complaint please Contact Above or
call at 01724647707 or Email at : customercare@clearline.co.in